



Cinecoustic Bar (Compact Sounbar)

BSBM111

User Manual

Important!

Please read this manual carefully before operating your product and retain this manual for future reference. Follow all instructions and explanations while handling & installing your product. Keep the operating instructions handy for later use. If the product is sold or passed on, then ensure that the new owner always receives this manual.

A little preventive care on your part can help prolong the life & usage of the product.

Read our user manual & warranty card carefully before operating the product and retain it for future reference.

Welcome to the BPL family!

Thank you for starting this journey with BPL. As a brand, BPL was never just about technology but about the meaning that technology adds to your lives. Our products are designed around you so that you may be able to live a fuller, more empowered life.

We hope you have a truly rewarding experience with BPL.

Your inputs and feedback are valuable to us, given we are on a quest of making life better for our family members spread all over the country.

Cheers!

Team BPL.

CONTENTS

E-WASTE MANAGEMENT	04
SAFETY INSTRUCTIONS	05
CONTROL PANEL DIAGRAM	06
TECHNICAL SPECIFICATION	07
PACKAGING CONTENT	07

E-WASTE MANAGEMENT

ENVIRONMENTAL INFORMATION

(Correct disposal of this product as per E-Waste Management and Handling Rules)

This marking on the product, accessories, or literature indicates that the product and its electronics accessories (e.g. charger, battery, cables, etc.) should not be disposed of with other household waste at the end of their working



Electronic equipment contains many hazardous metallic contaminants such as lead, cadmium, and beryllium and brominated flame retardants.

Improper handling and/or improper recycling of the Electronic Waste results in these hazardous metals/substances getting released into our eco and biological system, thereby leading to various health hazards. So, to prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Do's

1. Always drop your used electronic products, batteries, and accessories after the end of their life in the nearest authorised collection point/ centre or hand over to the authorised recycler for disposal.
2. Drop the discarded electronic equipment only in the bins meant for electronic waste.

Don'ts

1. The product and its accessories are not meant for mixing into the household waste stream or regular garbage bins.
2. Do not dispose of damaged or leaking Lithium-ion (Li-ion) battery with normal household waste.

INFORMATION FOR IMPROPER DISPOSAL & HANDLING

1. Any disposal through unauthorised agencies/persons will attract action under the Environmental (Protection) Act 1986.
2. If the batteries are not properly disposed of, they can cause harm to human health or the environment.

For more information on safe disposal and recycling, please call on Toll-Free No. 1800-309-0950 or visit our website www.bpl.in. This Product is RoHS Complaint ($\sqrt{\text{RoHS}}$).

PWM EPR Regd. No. BO-20-000-10-AABCR1718E-22

BWM EPR Regd. No. 1.1611832694039E+20

SAFETY INSTRUCTIONS

Important Safety Instructions



For your safety, the information in this manual must be followed to minimize the risk of fire or explosion, electric shock or to prevent property damage, personal injury or loss of life.

Before using the appliance, check for any damage. If there is any damage, do not use the appliance and immediately contact retailer / shopkeeper.

Do not operate the appliance with a damaged Cord / Plug or if it is dropped and damaged in any manner. If the product requires attention within the warranty period, call the toll-free number.

To protect against fire, electric shock or injury, do not place the Cord / Plug or appliance in water or any other liquid.

Do not let Cord hang over the edge of table or touch hot surfaces.

Do not place the appliance near any heat source.

Do not install the product in an area prone to combustible gas leaks, grease or metal dust.

This appliance is not intended to be used by the people including children with reduced physical, sensory or mental capabilities or a lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of the appliance by a person responsible for their safety.

To protect against electric shock, always unplug from the socket when not in use and before cleaning. To disconnect, remove Plug from the socket. Do not yank on the Cord as it may damage the Cord and eventually cause electric shock.


To avoid burns / cuts / risk of personal injury, use extreme caution while handling the appliance.

Do not use for other than intended use. This appliance is intended for household use only, not for Commercial or Industrial use. Use for anything other than intended will void the Warranty.

To avoid an electrical overload, do not operate another high-wattage appliance on the same power socket.

Avoid contact with pets, plants and insects when the appliance is in operation.

Control Panel Diagram



Function: Bluetooth/USB/TF/AUX/TWS/RGB light.

1. **Mode change:** click the button "M" to change the mode Bluetooth / USB/ TF/ AUX
2. **Previous track:** Long press the button "-" for previous track
3. **Decrease the volume:** Short Press "-" to decrease the volume
4. **Next track:** Long press the button "+" for next track
5. **Increase the volume:** Short Press the "+" to increase the volume
6. **Play/Pause:** click the " " to play or pause the music
7. **Lighting changing:** click the light button to change different light mode. After all light mode, press this button again then light will be off, and press it again, light will be on.
8. **Bluetooth mode:** When you turn on the speaker, it will be in Bluetooth mode automatically, Chose the "CineCoustic Bar Mini" to pair with the speaker
9. **TWS:** Turn on two speakers at the same time, and make sure both speakers are in Bluetooth mode, Long press the button " " of any speakers, you will hear a voice, that means TWS on, wait a few seconds, two speakers will connected with each other successfully.
10. **USB/TF/AUX:** Insert the USB, TF card and AUX cable into the slot of product backside. To enjoy the music.

Note



Product may be different as per shown in image.

TECHNICAL SPECIFICATION

Model No	BSBM111
Features	Buetooth, USB, TF, AUX, Dynamic Light
Product Dimensions	L*412*W75*H71mm
Wattage	35 W peak to peak
BT version	V5.4
Bluetooth Frequency	20Hz - 20Khz
Transmission Protocol	A2DP V1.0, AVRCP V 1.5 AVDTP 1.0, HFP V1.5
Transmission Distance	10m
Speaker Driver	52mm
Distortion	<10%
Charging Port	Type C

PACKAGING CONTENT

1. Soundbar	01 No.
2. Warranty Card	01 No.



**Experts at Your Service
for your product to perform at its best.**

**Reliance Retail Limited, Shed No. 111 and 120
Indian Corporation Godown, Mankoli Naka,
Dapode, Bhiwandi, Thane,
Maharashtra – 421302.**

**For Feedback / Complaints, please write to
customer@bpl.in
You may also reach us on our Toll-Free No.:
1800-889-1047**

**BPL is registered trademark of
BPL Limited and is used under license by
Reliance Retail Limited**

**Warranty Services will be limited to either repair or
replace the product at BPL's sole discretion.**